



SUPERIOR PRODUCTS INTERNATIONAL II, INC.

October 28, 2008

David Sparkman/Exxon Mobil

Dear David,

Below are the procedures for a CUI application for which you asked:


CUI (Corrosion-Under-Insulation) Application

- Ambient temperature should be between 60-100 degrees F.
- Surface temperatures should be above 60F under 125 F
- Remove existing insulation
- Prep surface to SP2
- Always be aware of condensation that can build at times and dew in the mornings. Do a solvent wipe just prior to application to assure surface is TOTALLY DRY. (Mineral Spirits)
- Apply 2 coats of Rust Grip at 6 mils wet, each coat. Apply the 2nd coat of Rust Grip after 1 hour or as soon as the 1st coat becomes tacky to the touch and has little-to-no transfer of coating.
- Apply 1 coat of Enamo Grip at 6 mils wet after 1 hour or as soon as the Rust Grip system becomes dry to the touch with no transfer of thumbprint.
- Both coating dry-times will be dependent on temperature and relative humidity. The higher the temperature and humidity, the faster the dry and cure time. Typically, 2-4 hours.

Please contact me with any questions or comments that you may have. Thank you.

Very truly yours,

SUPERIOR PRODUCTS INTERNATIONAL II, INC.

By: 
Craig R. Smith
Technical Director

CRS:xx